



**9800**

**9800 sudoFIT-Bogen 90°**  
egal innen-innen

<b>d - d</b>	<b>L</b>	<b>z</b>	<b>&amp;zeta;</b>	<b>VPE</b>	<b>Mat.</b>	<b>Art. Nr</b>	<b>Suissetec</b>
10-10	28	7	1.3	10	Rotguss	9800.10	232.113
12-12	31	8	1.2	10	Rotguss	9800.12	232.114
15-15	33	9	1.0	5	Rotguss	9800.15	232.115
18-18	41	11	0.8	5	Rotguss	9800.18	232.116
22-22	44	13	0.6	5	Rotguss	9800.22	232.117
28-28	57	16	0.9	2	Rotguss	9800.28	232.118
35-35	66	18	0.5	1	Rotguss	9800.35	232.121
42-42	81	22	0.4	1	Rotguss	9800.42	232.122