



**9801**

**9801 sudoFIT-Bogen 90°**  
innen-aussen mit Einsteckende

d - d	L	L1	z	z1	VPE	Mat.	Art. Nr	Suissetec
12-12	31	45	8	22	10	Rotguss	9801.12	232.114
15-15	33	47	9	23	5	Rotguss	9801.15	232.115
18-18	41	58	11	28	5	Rotguss	9801.18	232.116
22-22	44	60	13	29	5	Rotguss	9801.22	232.117
28-28	57	88	16	37	2	Rotguss	9801.28	232.118
35-35	67	107	19	55	1	Rotguss	9801.35	232.121