



9806

9806 sudoFIT-Übergangsbogen 90°
mit Aussengewinde konisch

d	L	l	L1	z	z1	VPE	Mat.	Art. Nr	Suissetec
15-1/2	33	23	32	10	19	5	Rotguss	9806.1507	232.335
18-1/2	41	29	39	12	26	5	Rotguss	9806.1807	232.336
22-3/4	44	30	42	14	27	5	Rotguss	9806.2209	232.347
22-1	44	30	45	14	28	5	Rotguss	9806.2211	232.357
28-1	57	41	48	16	33	2	Rotguss	9806.2811	232.358