



**9820**

**9820 sudoFIT-Übergang**  
mit Aussengewinde konisch

d	L	z	VPE	Mat.	Art. Nr	Suissetec
10-3/8	40	19	10	Rotguss	9820.1005	236.113
12-3/8	41	18	10	Rotguss	9820.1205	236.114
12-1/2	45	22	10	Rotguss	9820.1207	236.124
15-3/8	41	17	5	Rotguss	9820.1505	236.115
15-1/2	45	21	5	Rotguss	9820.1507	236.125
16-1/2	47	20	5	Rotguss	9820.1607*	
18-1/2	49	19	5	Rotguss	9820.1807	236.126
18-3/4	52	22	5	Rotguss	9820.1809	236.136
20-1/2	50	19	5	Rotguss	9820.2007*	
20-3/4	52	21	5	Rotguss	9820.2009*	
22-1/2	51	20	5	Rotguss	9820.2207	236.127
22-3/4	53	22	5	Rotguss	9820.2209	236.137
22-1	54	23	5	Rotguss	9820.2211	236.147
28-1	66	25	2	Rotguss	9820.2811	236.148
35-11/4	71	23	1	Rotguss	9820.3513	236.151
42-11/2	81	23	1	Rotguss	9820.4215	236.162

\* mit beiliegender Stützhülse installieren